

UNOFFICIAL COPY

THIS IS AN UNOFFICIAL, CLEAN TEXT VERSION OF THE NOTICE OF AMENDMENT PUBLISHED BY THE DNRC. FOR THE OFFICIAL ADMINISTRATIVE RULES OF MONTANA, VISIT THE SECRETARY OF STATE'S WEBSITE AT : <http://sos.mt.gov/ARM/index.asp>. THIS COPY WILL REMAIN ON THE DNRC SITE UNTIL THE OFFICIAL SOS SITE IS UPDATED.

36.12.101 DEFINITIONS Unless the context requires otherwise, to aid in the implementation of the Montana Water Use Act and as used in these rules:

- (1) "Act" means the Montana Water Use Act, Title 85, chapter 2, parts, 1-4, MCA.
- (2) "Amount" refers to both a flow rate in gallons per minute (gpm), or cubic feet per second (cfs), and a volume of water in acre-feet (af).
- (3) "Animal unit month (AUM)" means a measurement of livestock numbers.
 - (a) one beef cow = 1 AUM
 - (b) one dairy cow = 1.5 AUM
 - (c) one horse = 1.5 AUM
 - (d) three pigs = 1 AUM
 - (e) five sheep = 1 AUM
 - (f) 300 chickens = 1 AUM
- (4) "Applicant" means the person, as defined in 85-2-102(14), MCA, who files a permit or change application with the department.
- (5) "Application" for purposes of ARM 36.12.120 through 36.12.122, 36.12.1301, 36.12.1401, 36.12.1501, and 36.12.1601 means an application for beneficial water use permit, Form No. 600, including criteria addendum Form No. 600a, 600b or 600acf, or application to change a water right, Form No. 606, including criteria addendum Form No. 606a, 606b, 606asw, or 606t.
- (6) "Appropriation right" means any right to the use of water which would be protected under the law as it existed prior to July 1, 1973, and any right to the use of water obtained in compliance with the provisions and requirements of the act.
- (7) "Associated right" means multiple water rights filed by the same or different appropriators that share the same point of diversion, place of use, or place of storage.
- (8) "Augmentation plan" means a plan to provide water to a source of supply and its tributaries to mitigate the depletion effects of a permit or change authorization. The augmentation water right priority date is important to the success of any augmentation plan since call can be made on that water right. Examples of augmentation include, but are not limited to augmenting the source of supply with water from a nontributary source, or retiring all or a portion of senior water rights in the same source of supply in amounts equal to or greater than the depletion effects of the permit or change application.
- (9) "Basin closure area" means a hydrologic drainage basin area within which applications for certain water use permits cannot be accepted. Basin closure areas can be designated by statute, administrative rule, or in compacts.
- (10) "Certificate of survey number" means the official number given a parcel of land created by a registered land survey as filed with the county clerk and recorder.
- (11) "Cfs" means a flow rate of water in cubic feet per second and is equivalent to 448.8 gallons per minute. Applications for a flow rate of less than one cfs will be converted to gallons per minute.

(12) "Change authorization" or "change" means an approval by the department to make a change in appropriation right as defined by 85-2-102, MCA and allowed by 85-2-402, MCA.

(13) "Claim" means a statement of claim filed pursuant to 85-2-221, MCA, for a water right established prior to July 1, 1973.

(14) "Combined appropriation" means an appropriation of water from the same source aquifer by two or more groundwater developments, that are physically manifold into the same system.

(15) "Cone of depression" means a cone-shaped depression of water table or pressure surface developing around a pumping well.

(16) "Consumptive use" means the annual volume of water used for a beneficial purpose, such as water transpired by growing vegetation, evaporated from soils or water surfaces, or incorporated into products that does not return to ground or surface water.

(17) "Controlled groundwater area" means an area that has additional management controls applied to new ground water uses pursuant to 85-2-506 through 85-2-508, MCA.

(18) "Criteria addendum" means that additional portion of an application on which substantial credible information must address the criteria listed in 85-2-311 and 85-2-402, MCA.

(19) "Dam" means an artificial barrier created by man-made means designed to form a basin to hold water and create a pond or reservoir.

(20) "Deep percolation" means water that percolates below the root zone and infiltrates a deeper aquifer that is not used by other appropriators or connected to a surface water source.

(21) "Department" means the Montana Department of Natural Resources and Conservation (DNRC).

(22) "Domestic use" means those water uses common to a household including:

- (a) food preparation;
- (b) washing;
- (c) drinking;
- (d) bathing;
- (e) waste disposal;
- (f) cooling and heating; and
- (g) garden and landscaping irrigation up to five acres.

(23) "Drainage device" means a mechanism capable of draining or releasing substantially the full capacity of a reservoir.

(24) "Element" means the factors which describe a water right including, but not limited to:

- (a) the priority date;
- (b) source of supply;
- (c) point of diversion;
- (d) means of diversion;
- (e) period of diversion;
- (f) flow rate;
- (g) volume;
- (h) acreage;
- (i) purpose;
- (j) place of use;
- (k) period of use;
- (l) storage capacity; and

(m) storage location.

(25) "Existing right", in addition to the definition given the term by 85-2-102(8), MCA, includes any appropriation of water commenced prior to July 1, 1973, if completed according to the law as it existed when the appropriation was begun.

(26) "Evapotranspiration" means the loss of water from the soil both by evaporation and by transpiration from living plants.

(27) "Flow rate" is a measurement of the rate at which water flows or is diverted, impounded, or withdrawn from the source of supply for beneficial use, and commonly measured in cubic feet per second (cfs) or gallons per minute (gpm).

(28) "General abstract" means a department-generated document that reflects certain water right elements from the department's database.

(29) "Gpm" means a flow rate of water in gallons per minute.

(30) "Household" means the dwelling, house, or other domestic facilities where an individual, family, or social unit lives.

(31) "Hydraulically connected" means a saturated water-bearing zone or aquifer in contact with surface water or other water-bearing zone where rate of exchange of water between the two sources depends on the water level of the water-bearing zone or aquifer.

(32) "Hydrologic system" means the overall movement of water, including snow and ice, above, on or below the earth's surface.

(33) "Immediately or directly connected to surface water" means groundwater which, when pumped at the flow rate requested in the application and during the proposed period of diversion, induces surface water infiltration.

(34) "Induced surface water infiltration" means that water being pumped from a groundwater source is pulling surface water into the cone of depression.

(35) "Irrigation use" means the controlled application of water to land to supply water requirements not satisfied by rainfall.

(36) "Means of diversion" means the type of structures, facilities, or methods used to appropriate, impound, or collect water. Examples include, but are not limited to the following:

- (a) dike;
- (b) dam;
- (c) ditch;
- (d) headgate;
- (e) infiltration gallery;
- (f) pipeline;
- (g) pump;
- (h) pit; or
- (i) well.

(37) "Median year" means that water flow would be at the 50th percentile. Half of the years would have had higher flows and the other half would have had lower flows.

(38) "Multiple domestic use" means a domestic use by more than one household or dwelling characterized by long-term occupancy as opposed to guests. Examples are domestic uses by:

- (a) colonies;
- (b) condominiums;
- (c) townhouses; and
- (d) subdivisions.

(39) "Municipal use" means water appropriated by and provided for those in and around a municipality or an unincorporated town.

(40) "Notice area" means a geographic area determined by the department which may include water rights affected by an application.

(41) "Off-stream reservoir" means a reservoir that is not located on the source of supply and is supplied with water from a diversion means such as a pipe, headgate and ditch, or other means.

(42) "On-stream reservoir" means a reservoir that is located on the source of supply.

(43) "Owner of record" means a person who, according to the department's records, is the current owner of a water right.

(44) "Ownership update" means the updating of the department's water right ownership records by the filing of an ownership update form, Form No. 608, pursuant to 85-2-421 through 85-2-426, MCA. The department's form does not transfer water rights or legally determine water right ownership. It only updates the department's centralized ownership records as reflected by the legal documents that actually transfer water rights.

(45) "Period of diversion" means the period in a calendar year when water is diverted, impounded, or withdrawn from the source of supply. It is described by the earliest month and day and the latest month and day water is diverted during each year.

(46) "Period of use" means the period in a calendar year when water is used for specified beneficial use. It is described as the earliest month and day and the latest month and day the water is beneficially used during each year.

(47) "Place of use (POU)" means the land, facility, or site where water is beneficially used.

(48) "Point of diversion (POD)" means the location or locations where water is diverted from the source of supply.

(49) "Place of storage" means a reservoir, pit, pit-dam, or pond.

(50) "Pit, pit-dam, or pond" means a body of water that is created by man-made means, which stores water for beneficial use.

(51) "Possessory interest" means the right to exert some interest or form of control over specific land. It is the legal right to possess or use property by virtue of an interest created in the property though it need not be accompanied by fee title, such as the right of a tenant, easement holder, or lessee.

(52) "Primary diversion" means the initial point from which a diversion means will remove or impound water from the source of supply.

(53) "Priority date" means the clock time, day, month, and year assigned to a water right application or notice upon department acceptance of the application or notice. The priority date determines the ranking among water rights.

(54) "Project" means a place of use that has its own identifiable flow rate, volume, and means of diversion.

(55) "Recreational use" includes but is not limited to swimming, boating, water sports, and fishing.

(56) "Reservoir" means a pond, pit, or pit-dam, created by man-made means that impounds and stores water.

(57) "Return flow" means that part of a diverted flow which is applied to irrigated land and is not consumed and returns underground to its original source or another source of water, and to which other water users are entitled to a continuation of, as part of their water right. Return flow is not wastewater. Rather, it is irrigation water seeping back to a stream after it has gone underground to perform its nutritional function. Return flow results from use and not from water carried on the surface in ditches and returned to the stream.

(58) "Secondary diversion" means a diversion that is not from the source of supply but is a diversion that is used after the water is diverted from the source of supply at the primary diversion. For example, a pump in a ditch or reservoir is a secondary diversion.

(59) "Seepage water" means that part of a diverted flow which is not consumptively used and which slowly seeps underground and eventually returns to a surface or groundwater source, and which other water users can appropriate, but have no legal right to its continuance. Typical examples of seepage water include underground losses from an irrigation ditch or pond.

(60) "Senior water right" means a water right with a priority date that is earlier in time than another water right.

(61) "Source aquifer" means the specific groundwater source from which water is diverted for a beneficial use.

(62) "Source of supply" means the specific surface or groundwater source from which water is diverted for a beneficial use.

(63) "Spring" means a hydrologic occurrence of water involving the natural flow of water originating from beneath the land surface and arising to the surface of the ground. A developed spring is ground water if some physical alteration of its natural state occurs at its point of discharge from the ground, such as simple excavation, cement encasement, or rock cribbing. An undeveloped spring is surface water if no development occurs at its point of discharge and the appropriation is made from the waters flowing on the surface of the ground.

(64) "Stock use" means the use of water for livestock, including but not limited to cattle, horses, pigs, sheep, llamas, and animals owned and controlled on game farms. It does not include domestic animals such as dogs and cats or wild animals.

(65) "Surface water" means all water of the state at the surface of the ground, including but not limited to any river, stream, creek, ravine, coulee, undeveloped spring, lake, and other natural surface source of water regardless of its character or manner of occurrence.

(66) "Temporary authorization or temporary change" means an authorization to change granted pursuant to 85-2-407 and 85-2-408, MCA, for a specific period of time and with an automatic expiration date.

(67) "Temporary emergency appropriation" means the temporary beneficial use of water necessary to protect lives or property by reason of fire, storm, earthquake, or other disaster or unforeseen combination of circumstances which call for immediate action. An appropriation made necessary due to drought conditions is not a temporary emergency appropriation.

(68) "Temporary permit" means a permit to appropriate water granted pursuant to Title 85, chapter 2, part 3, MCA, for a specific period of time and with an automatic expiration date.

(69) "Transitory diversion" means a movable diversion that will divert water from several nonspecific points along a source of supply.

(70) "Tributary" means the following:

- (a) a surface water source feeding another surface water source; or
- (b) groundwater hydraulically connected to a surface water source.

(71) "Unnamed tributary" means a surface water stream, coulee, or draw, which is not named on a United States geological survey (USGS) or Water Resources Survey (WRS) map.

(72) "Use of water for the benefit of the appropriator" means:

- (a) the amount of water reasonably needed for the intended purpose;
- (b) the amount of water needed for conveyance to the intended purpose; and

(c) water used for instream flow.

(73) "Volume" means the acre-feet of water. Twelve acre-inches or 325,851 gallons are equal to one acre-foot.

(74) "Waste water" means that part of a diverted flow which is not consumptively used and which returns as surface water to any surface water source, and which other water users can appropriate, but have no legal right to its continuance. A typical example is an irrigator who turns into the individual furrows traversing the irrigator's field from the head ditch more water than can seep into the ground. The water that stays on the surface and is not absorbed into the earth and which remains at the end of the furrow and is collected in a waste water ditch is waste water.

(75) "Water flow estimating technique" means a mathematical method of estimating flow generally accepted by the department. This may be accomplished by correlating measurements of diversion system components with actual water use to estimate flow rate or volume of water used. An example is the use of measurements of power consumed by a pump to estimate the amount of water delivered by a pump. Another flow estimating technique would be to apply specific formulas developed by professional hydrologists based on climatic, basin or stream channel characteristics to estimate stream flow.

(76) "Water measuring device" means equipment that directly measures water flow in open or closed channels and conduits. Examples would be flow meters, weirs, flumes, and bucket and stop watch.

(77) "Water Resources Survey (WRS)" means a survey, by county, of water resources and water rights in Montana by the former State Engineer's Office or Water Resources Board, predecessors of the department.

(78) "Water saving method" means a change to the actual water use system or management of water use in which the modification being made would decrease the amount of water needed to accomplish the same result. Water saving methods might include:

(a) changing from a ditch conveyance to a pipeline;

(b) lining an earthen ditch with concrete or plastic; and

(c) changing management of a water system to decrease water consumption.

(79) "Zone of influence" means the horizontal extent of the cone of depression. (History: 85-2-113, MCA; IMP, 85-2-113, 85-2-301 through 85-2-319, 85-2-321 through 85-2-323, 85-2-329 through 85-2-331, 85-2-335 through 85-2-338, 85-2-340 through 85-2-344, 85-2-350, 85-2-351, 85-2-401, 85-2-402, 85-2-407, 85-2-408, 85-2-410 through 85-2-413, 85-2-415 through 85-2-419, 85-2-436, 85-2-437, 85-2-439, 85-2-501 through 85-2-514, 85-2-518, 85-2-520, MCA; NEW, Eff. 7/5/73; AMD, Eff. 2/4/75; AMD, 1987 MAR p. 1560, Eff. 9/11/87; AMD, 1992 MAR p. 1615, Eff. 7/31/92; AMD, 1993 MAR p. 1335A, Eff. 6/25/93; AMD, 2004 MAR p. 3036, Eff. 1/1/05; AMD, 2006 MAR p. 1387, Eff. 6/2/06; AMD, 2007 MAR p. 508, Eff. 3/26/07; AMD, 2007 MAR p. 1098, Eff. 8/10/07.)